


Glove Compartment

Removal

1.
1. Open the glove compartment


2. Remove the dampener.

3. Release the stop tabs, and fully lower the glove compartment.



Á	
Á	
Á	
Á	
Á	
Á	

2. Lift the glove compartment off the hinges and remove.



Á	
Á	
Á	
Á	
Á	
Á	

Installation

1. To install, reverse the removal procedure.