


Satellite Radio / Global Positioning System (GPS) Splitter / Cable


Removal

NOTE: Removal steps in this procedure may contain installation details.

1. Remove the information and entertainment display screen.
Refer to: [Center Display Screen](#) (415-00 Information and Entertainment System - General Information, Removal and Installation).
2. Disconnect the satellite radio/GPS splitter connectors.



3. Separate the satellite radio/GPS splitter antenna side cable from the guide, separate the splitter to ACM cable guide release the splitter module christmas tree retainers and remove the satellite radio/ GPS splitter.



Installation

1. To install, reverse the removal procedure.

© Copyright 2022, Ford Motor Company.