

Switching Neutral Tow On

- 1- Switch your vehicle to accessory mode by pressing the push button ignition switch without pressing any pedals.
- 2- Press the **2H** button on the four-wheel drive mode control.
- 3- Fully press and hold the brake pedal and shift the transmission to neutral (N).
- 4- Using the instrument cluster controls on the steering wheel, select **Settings**.
- 5- Select **Neutral Tow**.
- 6- Press and hold the OK button until a confirmation message appears in the information display.
- 7- Switch your vehicle off by pressing the push button ignition switch once **without pressing any pedals**.

Switching Neutral Tow Off

- 1- With your vehicle properly secured to the tow vehicle, switch your vehicle to accessory mode by pressing the push button ignition switch without pressing any pedals.
- 2- Starting with the brake pedal released and the transmission in neutral (N), fully press and hold the brake pedal for approximately seven seconds and shift the transmission to park (P). Continue holding the brake pedal until the instrument cluster display shows **2H** and **Neutral Tow Disabled**.